

## COMPRESSOR

### A.C. COMPRESSOR

Our brackets are designed for the popular Sanden SD5H14 508 AFTERMARKET compressors. These compressors are used by all of the specialty vehicle air conditioner companies. Most of these companies use our brackets as standard equipment with their air conditioning systems. Some Sanden part numbers for the 508 compressors are:

V-Belt	R134 - 6664
Serpentine Belt	R134 - 6629
Wide 5/8" Belt (Flathead Ford)	R134 - 6673

Aftermarket Sanden 510 and 709 compressors, while not commonly used, will also fit our brackets.

**NOTE:** some factory air systems use Sanden style compressors, THESE WILL NOT WORK with our brackets.

